



4 and 2: to the cylinder

Box: pushed

Lever

Box: at rest

Spring

1: air in. 5 and 3: exhaust.

The diagram illustrates a 5/2-way solenoid valve assembly. A central valve body is mounted on a purple plate. It features five ports: port 1 (top center) is connected to a red 'Air in' line; port 3 (top right) is connected to a 'Restrictor'; port 5 (top left) is connected to a 'Lever' actuator; port 4 (bottom left) and port 2 (bottom right) are connected to blue lines labeled 'To the cylinder'. A schematic symbol for a 5/2-way valve with a lever actuator is shown in the bottom right corner of the plate.

Lever pushed: air flows from port 1 to port 4. Port 2 exhausts through port 3.

Let go: the spring pushes it back. Air flows from port 1 to port 2. Port 4 exhausts through port 5.

A numbered hole where a pipe joins.